

GARMIN®



ТАСТИХ® 7

РЪКОВОДСТВО

© 2022 Garmin Ltd. or its subsidiaries

All rights reserved. Under the copyright laws, this manual may not be copied, in whole or in part, without the written consent of Garmin. Garmin reserves the right to change or improve its products and to make changes in the content of this manual without obligation to notify any person or organization of such changes or improvements. Go to www.garmin.com for current updates and supplemental information concerning the use of this product.

Garmin®, the Garmin logo, fēnix®, ANT®, ANT+®, Approach®, Auto Lap®, Auto Pause®, Edge®, inReach®, QuickFit®, TracBack®, VIRB®, Virtual Partner®, and Xero® are trademarks of Garmin Ltd. or its subsidiaries, registered in the USA and other countries. Body Battery™, Connect IQ™, Firstbeat Analytics™, Garmin Connect™, Garmin AutoShot™, Garmin Explore™, Garmin Express™, Garmin Golf™, Garmin Move IQ™, Garmin Pay™, Health Snapshot™, HRM-Dual™, HRM-Pro™, HRM-Run™, HRM-Swim™, HRM-Tri™, Rally™, tempe™, TrueUp™, Varia™, and Vector™ are trademarks of Garmin Ltd. or its subsidiaries. These trademarks may not be used without the express permission of Garmin.

Android™ is a trademark of Google LLC. Apple®, iPhone®, iTunes®, and Mac® are trademarks of Apple Inc., registered in the U.S. and other countries. The BLUETOOTH® word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Garmin is under license. The Cooper Institute®, as well as any related trademarks, are the property of The Cooper Institute. Di2™ is a trademark of Shimano, Inc. Shimano® is a registered trademark of Shimano, Inc. iOS® is a registered trademark of Cisco Systems, Inc. used under license by Apple Inc. STRAVA and Strava™ are trademarks of Strava, Inc. Training Stress Score™ (TSS), Intensity Factor™ (IF), and Normalized Power™ (NP) are trademarks of Peakware, LLC. Wi-Fi® is a registered mark of Wi-Fi Alliance Corporation. Windows® is a registered trademark of Microsoft Corporation in the United States and other countries. Zwift™ is a trademark of Zwift, Inc. Other trademarks and trade names are those of their respective owners.

This product is ANT+® certified. Visit www.thisisant.com/directory for a list of compatible products and apps.

Въведение

 **ВНИМАНИЕ**

Important Safety u Product Information

Първи стъпки

1 LIGHT

2

Garmin Pay™

3

4

Преглед на устройството



① Сензорен екран

-
-
-
-
-

② LIGHT

-
-
-
-

③ UP·MENU

-

④ DOWN

-

⑤ START·STOP

-

⑥ BACK·LAP

-
-
-

Активиране и деактивиране на сензорния екран

- DOWN START.
- MENU, System > Touch,

Използване на часовника

- LIGHT
- UP DOWN
- START
- MENU

Часовник

Задаване на аларма

- 1 MENU.
- 2 Clocks > Alarms > Add Alarm.
- 3

Редактиране на аларма

- 1 MENU.
- 2 Clocks > Alarms > Edit.
- 3
- 4

- Status.
- Time.
- Repeat,
- Sound and Vibe.
- Backlight.
- Label.
- Delete.

Стартиране на таймера за обратно отброяване

- 1 MENU.
- 2 Clocks > Timers.
- 3 MENU, Save Timer.
- 4 MENU Add Timer Quick Timer,
- Time
- Restart > On
- Sound and Vibe,
- 5 START

Изтриване на таймер

- 1 MENU.
- 2 Clocks > Timers > Edit.
- 3
- 4 Delete.

Използване на хронометъра

- 1 MENU.
- 2 Clocks > Stopwatch.
- 3 START
- 4 LAP



- 5 STOP,
- 6 .
- . DOWN.
- . MENU, Save Activity.
- . MENU, Done.
- . MENU, Review.
- . Review
- . MENU, Go to Watchface.
- . MENU, Lap Key.

Добавяне на алтернативни часови зони

- 1 MENU.
- 2 Clocks > Alt. Time Zones > Add Alt. Time Zone.
- 3
- 4

Редактиране на алтернативна часова зона

- 1 MENU.
- 2 Clocks > Alt. Time Zones > Edit.
- 3
- 4
 - Rename Zone.
 - Change Zone.
 - Reorder Zone.
 - Delete Zone.

Летене

⚠ ВНИМАНИЕ

Important Safety and Product Information

Избор на любимо летище


- 1 MENU.
- 2 Aviation > Favorite Location.
- 3
 - Search by Ident.
 - Nearest
 - Flight Plan.
- 4

Разглеждане на метеорологичен радар NEXRAD

NEXRAD,

: NEXRAD Tiles Aviation,

- 1
- 2 START.
- 3 NEXRAD.
- 5



Летателна дейност

Стартиране на полет

- 1 START.
- 2 Fly.
- 3
- 4 START,
- 5
- 6 STOP Save.

Преглед на показанията на SpO2 по време на полет

⚠ ВНИМАНИЕ

SpO2

tactix 7

(SpO2).

SpO2.


SpO2,

SpO2.



Навигация до най-близкото летище

- 1 START.
- 2 Fly.
- 3 MENU.
- 4 Navigation > Flight Planning > Find Waypoint > Nearest Airports.



①	-
②	-
③	-
④	METAR

- 5
- 6 Direct-To.
- 7 START,

Спиране на навигацията

MENU Stop Navigation.

Преглед на информация за пътна точка

1

2

-
-
-
- METAR, TAF MOS Airport Info
- : MOS Airport Info > Frequencies.
- Runway Info. Airport Info >
- Info Airport Info > Airport Info. General
- Weather.

Индикатор за хоризонтална ситуация

⚠ ВНИМАНИЕ



①	
②	(CDI).
③	" "
④	
⑤	
⑥	Bearing -
⑦	(ETE).

Деактивиране на автоматичния таймер за полет

30 kt.

- 1 MENU.
- 2 Activities & Apps > Fly.
- 3
- 4 Flight Timer > Manual.

Маршрути и полетни планове

Намиране на пътна точка

- 1 START.
- 2 Fly.
- 3 MENU.
- 4 Navigation > Flight Planning > Find Waypoint.
- 5 :
 - Search by Ident.
 - - Nearest Airports.
 - - Nearest Airports.
 - intersections, Nearest Intersection.
- 6
- 7

Създаване на полетен план на вашия часовник

- 1 START.
- 2 Fly.
- 3 MENU.
- 4 Navigation > Flight Planning > Saved Plans > Create New.
- 5
- 6 ✓
- 7 Add Location.
- 8
- 9
- 10 7 9,
- 11

Следване на план

- 1 START.
- 2 Fly.
- 3 MENU.
- 4 Navigation > Flight Planning > Saved Plans.
- 5
- 6 Set Active,

Преглед на полетен план на картата

- 1 START.
- 2 Fly.
- 3 MENU.
- 4 Navigation > Flight Planning > Saved Plans.
- 5
- 6

Обръщане и следване на полетен план

- 1 START.
- 2 Fly.
- 3 MENU.
- 4 Navigation > Flight Planning > Saved Plans.
- 5
- 6 Invert Save Copy,
- 7
- 8 Set Active,

Редактиране на полетен план



- 1 START.
 - 2 Fly.
 - 3 MENU.
 - 4 Navigation > Flight Planning > Saved Plans.
 - 5
 - 6 Edit.
 - 7
 -
 -
 -
 -
 -
- Details.
Move Up Move Down
Name.
Remove.
Add Location.

Изтриване на полетен план

- 1 START.
- 2 Fly.
- 3 MENU.
- 4 Navigation > Flight Planning > Saved Plans.
- 5
- 6 Delete > Yes.

Преглед на вашата издръжливост в реално време


- VO2 max.
- 1 MENU.
 - 2 Activities & Apps.
 - 3
 - 4
 - 5 Data Screens > Add New > Stamina.
 - 6 UP DOWN ().
 - 7 START ().
 - 8
 - 9 Натиснете UP или DOWN



Пулсов оксиметър

Garmin Connect

garmin.com/ataccuracy



①	
②	24
③	
④	
⑤	24

Garmin Connect

Garmin Connect. Garmin Connect

(garmin.com/connectapp)

connect.garmin.com.

Garmin Connect



Garmin Connect

зползване на приложението Garmin Connect

Garmin Connect,

Garmin Connect.


1 Garmin Connect

2 10 (30)

Garmin Connect

Garmin Connect.

Мога ли да използвам своя Bluetooth сензор с моя часовник?



Слушалките ми не се свързват с часовника



Музиката ми спира или слушалките ми не остават свързани



Рестартиране на вашето устройство



Нулиране на всички настройки по подразбиране



Моят дневен брой стъпки не се показва

Моят брой стъпки не изглежда точен

-
-
-

Броя крачки на моето устройство и моя акаунт в Garmin Connect не съвпадат

Garmin Connect

1

-

Garmin Express.

-

Garmin Connect.

2

Garmin Connect

Garmin Express

Количеството изкачени етажи не изглежда точно

3 m (10 ft).

-
-

